




Squeeze the sides of the security latch.



Move released latch upward.



Insert the frame wire into the throat of the open hook.



Allow the frame to rest on the hook and snap the latch in the lower position to secure the art piece.

This hook may also be used without the security latch by removing it from the hook assembly prior to inserting a cable into the hook.

When used with the security latch in place this hook will counteract many of the risks from earthquakes.

ASHanging.com  
866.935.6949