




Casso® Shelf K3145, K3146

PART LIST



Warning

Use the Casso Shelf only with the Casso Display Rail or Casso Magnetic Display Rail. Other accessories are available: Casso J Hanger, Label Frame and Storage Bin.

1 Casso® Shelf Installation

- Put the top lip of the shelf at an angle on the wall-mounted Casso® Display Rail.
- Push on the bottom part of the Shelf until you hear a click sound.
- The Casso® Shelf is now installed and can be moved/slided from left to right along the rail.

2 Removal of the Casso® Shelf

- Pull the top and bottom of the shelf towards you.
- Lift up the Casso® Shelf.