




Casso® Storage Bin K3147, K3148

PARTS LIST



Warning

Use the Casso Storage Bin only with the Casso Display Rail or Casso Magnetic Display Rail. Other accessories are available: Casso J Hanger, Label Frame and Shelf.

1 Casso® Storage Bin Installation

- Put the top lip of the Storage Bin at an angle on the wall-mounted Casso® Display Rail.
- The Storage Bin is now installed and can be moved/slided left to right along the rail.

2 Removal of the Casso® Storage Bin

- Put one hand on the top of the Storage Bin. The other hand pulls the bottom of the Bin towards you.
- Lift up the Storage Bin.