


Cable Trim Kit U5150AA

Compatibility
Galvanized or Stainless Steel Cables



Warning

BONDS TO SKIN INSTANTLY. Do not put in eyes, mouth or on skin. Keep out of reach from children. **FIRST AID TREATMENT:** Contains ethyl cyanoacrylate. Eyelid bonding: SEE A DOCTOR. Skin bonding: soak in water and call a Poison Control Center. **DO NOT** force apart.

1 Directions to trim Steel Cable without fraying end


- Wear protective gloves, goggles and long sleeves.
- Remove one tube and nozzle from package and reserve balance of Super Glue tubes for future use.
- Using a marking pen, make a mark on the cable where you will cut. Repeat on each cable that needs to be trimmed.
- While mark dries apply self-penetrating nozzle to Super Glue tube. Do not apply pressure to tube as glue will immediately release.
- Apply one or two drops of glue to the mark on each cable to be trimmed.
- Allow the glue to dry for 5 – 10 minutes.
- Use cable cutter to cut cable on the earlier mark. Cable should not fray.




NOTE

This glue should not be applied to Styrofoam, foam rubber, polyethylene or polypropylene plastics.


Make a mark on the cable



Apply glue to the mark



Use cable cutter to cut cable



ASHanging.com/cable-trim-kit

ASHanging.com
866.935.6949