


INSTRUCTIONS GUIDE

Cable Trim Kit U5150CA

Compatibility
Galvanized or Stainless Steel Cables





Warning

BONDS TO SKIN INSTANTLY. Do not put in eyes, mouth or on skin. Keep out of reach from children. FIRST AID TREATMENT: Contains ethyl cyanoacrylate. Eyelid bonding: SEE A DOCTOR. Skin bonding: soak in water and call a Poison Control Center. DO NOT force apart.


1 Directions to trim Steel Cable without fraying end


- · Wear protective gloves, googles and long sleeves.
- Remove child-proof lid. Remove one tube and nozzle from container and restore lid, reserving balance of Super Glue tubes for future use.
- Using a marking pen, make a mark on the cable where you will cut. Repeat on each cable that needs to be trimmed.
- While mark dries apply self-penetrating nozzle to Super Glue tube. Do not apply pressure to tube as glue will immediately release.
- Apply one or two drops of glue to the mark on each cable to be trimmed.
- Allow the glue to dry for 5 10 minutes.
- Use cable cutter to cut cable on the earlier mark. Cable should not fray.




NOTE

This glue should not be applied to Styrofoam, foam rubber, polyethylene or polypropylene plastics.







ASHanging.com/en_ca/cable-trim-kit-ca

ASHanging.com 866.935.6949