




Drop Ceiling Track A1080HF



PARTS LIST




Warning

The track is supplied with screws and TripleGrip® plastic screw anchors that are suitable for mounting the track to gypsum panels, lathe and plaster, concrete, wood, etc. All holes in track should be filled with a suitable screw/fastener combination.

Property damage and personal injuries can occur from track mount failure. To prevent such failure it is the responsibility of the installer to select a suitable fastener for a specific installation.


1 Check Walls

- The wall should be straight, Drop Ceiling Track is rigid and does not easily bend.
- Normal track orientation is horizontal.





2 Measure

- Measure your ceiling segments. Drop Ceiling Track replaces the corner profile (perimeter L Molding) used in recessed ceiling.



Proper Blade



3 Cut or Trim Track

- Cut track as needed and remove all burrs.



TIP

Cut the track with a hack saw and miter box or power miter saw with proper blade.






TIP

To join two tracks at an inside/outside 90° corner, cut both ends at 45° to have a perfect fit.



Top View





4 Mark and Prepare Holes


- Trial place each track length and mark mounting holes.

TIP


Use a level to make certain track is level.

- Use a stud finder or drill 1/16" pilot holes to probe for wall structure.

Anchor





Screw



5 Mounting Track on Walls

- If no structure is present, expand the hole to 1/4" and insert supplied anchors.
- Fasten track to prepared holes with supplied fasteners.



6 Install Recessed Ceilings

- Follow the instructions provided by the supplier of the suspended ceiling purchased. The Drop Ceiling Track replaces the corner profile (perimeter L Molding) used in recessed ceiling.