




Shadowline Wall Track A1086HF



PARTS LIST



Warning


The track is supplied with screws and TripleGrip® plastic screw anchors that are suitable for mounting the track to gypsum panels, lathe and plaster, concrete, masonry block, etc. All holes in track should be filled with a suitable screw/fastener combination.

Property damage and personal injuries can occur from track mount failure. To prevent such failure, it is the responsibility of the installer to select a suitable fastener for a particular installation.

1 Check Walls

- The wall should be straight, Shadowline Wall Track is rigid and does not easily bend.

Straight Wall



Non-linear Wall

- Normal track orientation is horizontal.


2 Measure

- Measure your wall segments.
- Install your tracks wall-to-wall



TIP

To join two tracks at an inside/outside 90° corner, cut both ends at 45° to have a perfect fit.




Ceiling



Wall



Top View



Proper Blade





3 Cut or Trim Track

- Cut track as needed and remove all burrs.



TIP

Cut the track with a hack saw and miter box or power miter saw with proper blade.



4 Mounting Track

- Trial place each track length and mark mounting holes.




TIP



Use a level to make certain track is level.

- Use a stud finder or drill 1/16" pilot holes to probe for wall structure (stud).
- If no structure is present, expand the hole to 1/4" and insert supplied anchors.
- Fasten track to prepared holes with supplied fasteners.

Anchor



Screw



5 Gypsum Board Installation/Plaster Application

- Insert your gypsum panels into the opening along the entire track length.
- Apply plaster on the exposed track portion.



IMPORTANT

Do not put plaster in the opening where the cable will be inserted.